



ITEM	PARTS NO	PARTS NAME	ITEM	PARTS NO	PARTS NAME
101	2040101-04161-2	HEX.SOC.HD.BOLT	401	2041104-08020-0	O - RING
102	11369-103C401-1	CAP	402*	11383-1110001-1	MUZZLE PROTECTOR
103	11355-0350001-1	GROMMET	403	11382-1114701-1	NOSE PIECE
104	2040104-03010-0	HEX.SOC.HD.SCREW	404	2040101-06010-2	HEX.SOC.HD.BOLT
105	11397-1034701-1	GUIDE COVER	405*	2041100-01091-0	O - RING
106*	11302-1034701-1	CYLINDER CAP SEAL	406	11364-0974702-1	FEED PISTON-B
107*	11370-1030001-1	SEAL	407*	2041104-03040-0	O - RING
108	11360-1030001-2	COMPRESSION SPRING	408	1134W-0970001-1	FEED BUMPER
109*	2041108-06050-0	O - RING	409	2040100-04080-2	BOLT ASSY
110	11381-1030001-1	WASHER	410	11367-1030001-1	PUSHER SPRING
111	11368-1030001-1	HD.VALVE PISTON	411	11366-0974701-1	FEED PISTON CAP
112*	2041108-07050-0	O - RING	412	2040300-08010-0	C - RING
113*	2041100-06011-0	O - RING	413	1134B-0864701-1	DUST SHIELD PLUG
114*	11204-1110001-1	DRIVER UNIT	414	11310-0254702-2	LOCK LEVER
115	11399-1030001-1	COLLAR	415	11311-1030001-1	LATCH SPRING
116	11320-1110001-2	CYLINDER	416	11361-1114701-1	DOOR
117	11321-1110001-1	CYLINDER SPACER	417	1135H-0860001-1	PU RETAINER
118	2041104-11010-0	O - RING	418	1131K-1034701-1	PIN
119	2041108-07060-0	O - RING	419	1133C-0860001-1	STOPPER FINGER SPRING
120*	11327-1034702-1	BUMPER-A	420	11358-1114701-1	NAIL STOP
121	2040101-03050-9	HEX.SOC.HD.BOLT	421	11359-1114701-1	PIN-NAIL STOP
122	11371-1034701-1	DEFLECTOR	422	11362-1034701-1	DOOR SHAFT PIN
123	1132T-1030001-1	MUFFLER	423	11330-1114701-1	SAFETY
124*	11327-1034703-1	BUMPER-B	424	11337-1030001-1	SAFETY SPRING
125	1130E-111C401-1	CAP	425	11338-0864701-2	SAFETY GUIDE
201	2041104-02060-0	O - RING	426	11354-1114702-1	MAGAZINE CASE
202	11374-0860001-1	PLUNGER CAP	427	11357-1034704-1	ADJUST POST
203	2041100-02050-0	O - RING	428	2040301-24010-0	S - RING
204	2041100-01070-0	O - RING	429	1134M-0864701-1	SPRING BASE
205	1133S-0860001-1	VALVE PLUNGER	430*	11289-1110001-1	SPACER
206	2041100-01030-0	O - RING	431	1138W-0860001-1	SPACER
207	11376-0860001-1	SPRING	432	11328-1114701-1	PULL SPRING
208	2041108-01020-0	O - RING	433	11355-1114701-1	MAGAZINE COVER
209	11375-0860002-1	PLUNGER	434	11365-0864701-1	PIN FEED PISTON
210	11373-0860001-1	TRIGGER VALVE HEAD	435	11306-1114701-1	FEED FINGER
211	11329-0860001-1	PIN	436	11364-0974701-1	FEED PISTON-A
212	1137A-0860001-1	COVER-PLUNGER	437*	11307-0970001-1	FEED FINGER SPRING
213	2041104-02070-0	O - RING	438	2040101-04131-0	HEX.SOC.HD.BOLT
214	2041100-01050-0	O - RING	439	1134R-1114701-1	SPRING COVER
215	2040401-05150-0	SPIRAL PINS	440	2040501-04010-0	BOLT CAP
217	11224-1111101-2	TRIGGER UNIT	441	1136R-1034701-1	MAGAZINE SHAFT PIN
219	2040401-05120-0	SPIRAL PINS	442	2040202-04010-0	FLAT WASHER
220	11376-0370001-1	SPRING	444	1131D-0460001-1	URETHANE RETAINER
301	11230-1030601-2	GUN BODY UNIT	445	1135U-1010001-1	PROTECTOR WASHER
302	2041101-05020-0	O - RING	447	1120K-1034701-1	SECOND HANDLE BASE UNIT
303	11346-0864304-1	END CAP	449	2040101-04121-0	HEX.SOC.HD.BOLT
305	1135V-0000017-1	AIR PLUG	450	1135G-1114701-1	RUBBER PAD